

**Exploded View and Parts List**

With the exception of maintenance items, such as Teflon sheets, electrical and mechanical parts should be replaced only by a qualified service representative.

No.	Part No.	Description
1	526-073S	Membrane Switch w/Overlay
2	526-021S	Display Board
3	525-136S	Main Board
4	85-144-25S	Power Supply Board
5	526-732S	Motor
6	526-023S	Fan (qty. of 2)
7	526-032S	Handle (qty. of 2)
8	78-233S	Power Switch
9	525-278S	Platen
10	65-058S	SS Relay 50A
11	65-058S	Power Relay
12	525-205S	Air Shield
13	525-123S	Bearing Assembly
14	525-127S	Cutoff Switch
15	526-281S	Hi Limit

No.	Part No.	Description
16	72-458S	Power Cord - DCFT-BKCE
16	72-459S	Power Cord - DCFT-BKCEUK
17	70-081S	Knobs (qty. of 2)
18	525-004S	Teflon Sheet
19	77-092-03S	Terminal Block
20	526-022S	Probe
21	525-090S	Major Side Overlay
22	525-137S	Drive Train Assembly
23	525-138S	Drive Chain
24	86-584S	Tensioner Spring
25	525-099S	Tensioner Assembly
26	525-140S	Air Shield Spring Kit
27	525-202S	Kit, In Feed Assembly
28	525-268S	DCFT-BKCE (UK) Retro Fit Kit
29	525-002S	Service Kit, Ramp

